






Assembly Instruction Flexible Solid Flooring System in tents









**Distances inside the tent to string:
tent 10 x 24 m²: approx. 100 mm
tent 10 x 32 m²: approx. 250 mm**











Distances inside tent to first plate:
tent 10 x 24 m²: approx. 190 mm
tent 10 x 32 m²: approx. 190 mm


















Number of full plates in one row:
Tent 10x24 m²: Max 17
Tent 10x32 m²: Max 17



















Number of full plates in opening:


Tent 10x24 m²: 7 plates


Tent 10x32 m²: 7 plates













Number of triangles left:


Tent 10x24 m²: Max 10


Tent 10x32 m²: Max 10

Number of triangles right:

Tent 10x24 m²: Max 10

Tent 10x32 m²: Max 10








Number of half left:
Tent 10x24 m²: Max 24
Tent 10x32 m²: Max 33

Number of half right:
Tent 10x24 m²: Max 24
Tent 10x32 m²: Max 33





Total Number of Baseplates:

Tent 10x24 m²: Max 833

Tent 10x32 m²: Max 1136

